

TRIM-TEX

DRYWALL PRODUCTS

Flat Tear Away

Creates a finished edge where drywall terminates at other substrates or building components such as windows and doors. Designed for areas where the drywall has been butted too close to slip a return leg behind the drywall.

Installation Instructions

Step 1: Measure and cut the bead to length. Dry fit to test proper cut.

Step 2: Spray the bead and corner with 1 coat each of Trim-Tex 847 Spray Adhesive and position the bead into place.

Step 3: Once in position, pressure the leg using a Trim-Tex installation tool or the handle of your taping knife.

Step 4: Staple the mud leg into place every 6"-8" with ½" staples.

Step 5: Mud as usual. Be sure to use All-Purpose or Multi-Purpose Compound. Add Mud-Max to your drywall compound for extra durability.

Step 6: Remove the tear-off strip after mudding but before sanding. Prime and paint as usual.

